



STANDARD BOX INSTALLATION INSTRUCTIONS **VARIOUS MODELS**

Please read before beginning

- *Stainless steel hardware may bind together when tightening—It is recommended that you apply an anti-seize assembly lubricant to the threads of each bolt before assembly*

Required tools

- Standard wrench set
- Philips head screwdriver
- Electric drill
- 1/4" Drill bit



Included hardware

Quantity

- | | |
|-------------------------------------------------------------|---|
| • 70008- 1/4-20 Nut with nylon locking insert | 3 |
| • 70009- 1/4 ID x 5/8 OD Washer, Stainless steel | 3 |
| • 70038- 1/4-20 x 2 3/4" Philips head countersink cap screw | 3 |
| • 70039- 1/4" Fender Washer Stainless steel | 3 |
| • 70040- 1/4 ID Countersink washer | 3 |
| • Anti-seize packet, 2g | 1 |

Assembly instructions

- Ignore the flanges
- Place the box on the swing arm.
- Drill a 1/4" hole through the box & pipe in 3 places. Fasten each bolt as you drill the hole to prevent the box from moving
 - If possible, drill a hole through the box and vertical pipe in the upper right-hand corner as you face the back of the van
- Fasten the box to the vertical swing arm pipe (see picture below)
 - The 1/4" bolts should go through the counter sunk washer then the pipe
 - On the other side of the pipe put the regular washer on then the 1/4" Nylock Nut

